




COMMERCIAL ELECTRIC DRYER

MODELS:

MDE18PRAYW0 (White)
MDE18PRAZW0 (White)

BDSPARTS.COM

TOP AND CONSOLE PARTS




TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10135415	Card Reader, Conversion Kit	22	98139	Screw
	W10474273	Installation Instructions	11	W10143462	Screw	23	W10137770	Retainer, Card Reader Cover
	W10135291	Instructions, Installation (Card Reader)	12	W10471563	Control Board	24	3400618	Screw
	W10183571	Tech Sheet	13	W10133514	Standoff, Circuit Board	25	W10137769	Cover, Card Reader
2	W10267645	Cover, Display	14	W10139046	Nut, 6-32	26	W10133282	Jumper, Switch Service/Vault
3	W10386302	Screw	15	W10161476	Shield, Probing	27	W10133335	Relay, Motor
4		Fascia	16	W10461095	Console	28	8533971	Screw
5	W10136704	Top	17	W10131123	Nut, "U"	29	W10131839	Transformer
6	W10137322	Screw	18	W10131115	Bezel	30	W10130183	Harness, Main
7	W10133304	Card Reader, Harness	19	8317305	Panel, Rear Console			
8	W10461122	Bracket, Control	20	3390647	Screw			
9	W10133515	Deflector Switch Assembly	21	W10286180	Cover, Terminal Block			

BDSPARTS.COM


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	3393008	Screw	19	W10291934	Clip	39	W10212660	Motor, Sound Pad
2	W10131123	Nut, "U"	20	345670	Lock Top	40	W10155571	Switch, Assembly
3	3391846	Clip, Front Panel	21	W10279703	Hinge & Pin Assembly	41	3406109	Switch, Door
4	3400077	Screw	22	W10386302	Screw	42	W10002600	Screw
5	8564010	Assembly, Switch & Actuator	23	3391943	Boot, Foot	43	697215	White
6	3397659	Block, Terminal	24	697773	Screw	44	3387242	Seal, Front Panel
7	W10547697	White	25	693152	Bumper	45	342055	Screw
8	3392100	Foot, Dryer	26	3393657	Restrainer, Belt	46	3388229	Retainer
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	27	W10396034	Assembly, Motor 60 HZ.	47	W10323061	Door, Rear
9	660658	Clamp, Motor	28	3394341	Pulley, Motor	48	695240	Screw
10	W10446781	Spring, Idler	29	8533974	Screw	49	W10322546	Door, Front
11	3389420	Screw	30	W10131172	Belt, Drive	50	W10116360	Handle, Door
12		Plug, Multivent	31	3390902	Clip, Door Hinge	51		Panel, Front
	697750	White	32	W10135695	Bracket, Motor		W10192882	White
13	W10344192	Assembly, Idler	33	3392186	Washer	52	696144	Strike, Door
14	3391915	Screw	34	279318	Terminal, Brass & Tinned (Includes Terminal Block Screw Kit)	54	3392538	Door Catch Assembly
15	3394331	Cover Plate, Exhaust Plate	35	279393	Screw Kit, Terminal Block	55	3390647	Screw
16	W10167613	Wire, Belt Switch	36	3390663	Screw, Door Switch Mounting	56	3390735	Seal, Door
17	W10191265	Plug, Hinge	37	49026	Elbow	57	279818	White
18	8539892	Wire, Motor To Belt Switch	38	8564011	Bracket, Switch			Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	16	W10001120	Nut, Hex (Left Hand Thread)	30	3392519	Fuse, Thermal (91C)
2	90767	Screw	17	3387809	Bulkhead, Rear	31	359625	Screw
3	8533971	Screw	18	3387459	Washer	32	3391914	Thermostat HL-295/215
4	8066086	Plug, Drum Hole	19	W10359272	Shaft, Drum Roller - Left Hand Thread	33	W10181926	Grille, Outlet
5	697354	Assembly, Air Duct	20	690997	Washer, Tri Ring	34	697557	Bulkhead, Front
6	697813	Seal, Outlet Housing	21	W10314171	Roller, Support	35	697693	Baffle, Drum
7	697814	Seal, Drum Front	22	697770	Seal, Plate Cover	36	3357011	Screw
8	3934666	Nut, Hex	23	W10181928	Housing, Outlet	37	W10349492	Wheel, Blower
9	8066224	Pipe, Exhaust	24	8318314	Kit, Thermal Cut-Off (Includes High Limit Thermostat)	38	W10181925	Door, Lint Screen
10	8572105	Clip, Exhaust	25	W10545923	Assembly, Drum	39	W10131836	Thermostat
11	693995	Screw	26	W10219342	Screw	40	3387230	Screw
12	3392537	Assembly, Weld Heater Box	27	W10521118	Seal, Drum	41	W10135254	Housing, Blower
13	3390647	Screw	28	3394986	Spring, Lint Screen Door	42	8066168	Assembly, Lint Duct
14	3387748	Element, Heater	29	8066099	Bracket, Heater Box	43	W10345456	Clip, Spring
15	W10049370	Screen, Lint				44	W10193019	Thermostat (155~F) Electronic

BDSPARTS.COM

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

BDSPARTS.COM