

PARTS LIST

for

MAYTAG[®]


**COMMERCIAL
ELECTRIC DRYER**

MODEL

MDG17MNAWW0

TOP AND CONSOLE PARTS

For Model: MDG17MNAWW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


TOP AND CONSOLE PARTS

For Model: MDG17MNAWW0
(White)

Illus.	Part	
No.	No.	DESCRIPTION
1		Literature Parts
	W10135130	Instructions
		Installation
	W10167625	Wiring Diagram
	W10135146	Repair Parts List
2	W10133502	Lens, Pilot Light Amber
3	W10131119	Screw
4	W10135184	Facia / Overlay
5	W10146429	Nut, 8-32 x 3/8
6	W10139799	Washer
7	W10139100	Screw
8	W10124216	Bracket, Control
9	W10157942	Timer, Dryer
10	W10129712	Switch, Cycle Selection
11	W10149462	Switch, Push-To-Start
12	W10130072	Lamp-Indicator 120 V.
13	W10133507	Knob
14	W10133505	Knob, Control
15	W10133506	Skirt, Dial
16	W10137300	Console
17	W10131123	Nut, #8 U Type
18	W10139210	Screw
19	8317305	Panel, Rear (Upper)
20	3390647	Screw
21	8317340	Cover, Terminal Block
22	3390814	Screw
23	W10140928	Clip, Knob
31	W10136704	Top
32	W10153155	Harness, Main
33	W10155650	Nut, 1/4-28 x
34	W10133501	Cap, Knob

CABINET PARTS

For Model: MDG17MNAWW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: MDG17MNAWW0
(White)


Illus. No.	Part No.	DESCRIPTION
1	3387057	Screw
2	W10131123	Nut, #8 U Type
3	3391846	Clip, Front Panel
4	3400077	Screw
5	8564010	Switch, Broken Belt
6	3393909	Screw
7	8310656	Cabinet
8	3392100	Foot, Dryer (Plastic)
	279810	Foot – Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12	697750	Plug, Multivent
13	W10141380	Idler Assembly
14	3391915	Screw
15	3394331	Plate, Cover
16	W10167613	Wire, Belt Switch
19	297092	Clip
21	3389247	Hinge And Pin
22	W10131119	Screw

Illus. No.	Part No.	DESCRIPTION
23	3391943	Boot, Foot
24	697773	Screw
25	693152	Bumper
26	3389249	Nut, "U"
27	W10139766	Motor Assembly (60 Hz.)
28	3394341	Pulley
29	8533974	Screw
30	W10131172	Belt, Drive
31	3390902	Clip, Door Hinge
32	W10135695	Bracket, Motor
33	3392186	Washer
34	686590	Ignitor
35	W10141728	Valve Gas 60Hz. (Complete)
36	3390663	Screw
37	279731	4" – 90° Elbow
38	8564011	Bracket, Switch
40	W10155571	Switch Assembly
41	3406109	Door Switch Assembly
42	W10002600	Screw
43	697215	Panel, Toe
44	3387242	Seal, Front Panel
45	342055	Screw
46	3388229	Retainer

Illus. No.	Part No.	DESCRIPTION
47	3392563	Door, Rear
48	694091	Screw
49	3387872	Door, Front
50	3389522	Handle, Door
51	3393081	Front Panel
52	696144	Strike, Door
53	8539892	Wire, Jumper
54	3392538	Catch, Door Assembly
55	3390647	Screw
56	3390735	Seal, Door
57	345670	Lock, Top
58	W10135231	Burner Assembly 60 Hz. (Refer To Pages 8 & 9 For Further Breakdown)
59	3393657	Belt, Restrain
60	3405160	Belt, Poly V
61	3401401	Cord, Power
<hr/> Optional Parts Not Included <hr/>		
<hr/> Dryer Exhaust Kit (For Side & Bottom Venting) <hr/>		
62	279818	White

BULKHEAD PARTS

For Model: MDG17MNAWW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS


For Model: MDG17MNAWW0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	15	W10049370	Screen, Lint	30	3392519	Thermal Limiter
2	90767	Screw	16	W10001120	Nut, 3/8-16 (L.H.)	31	487909	Screw
3	8533971	Screw	17	3387809	Bulkhead, Rear	32	8573028	Thermostat High-Limit 205 F (96 C)
4	8066086	Drum Hole Plug	18	3387459	Washer, Support	33	8563756	Grill, Outlet
5	3394346	Air Duct Assembly	19	8575325	Shaft, L.H. Thread	34	697557	Bulkhead, Front
6	697813	Seal, Outlet Housing	20	690997	Ring, Tri	35	697693	Baffle, Drum
7	697814	Seal, Drum Front	21	8536973	Roller, Support	36	3357011	Screw
8	3934666	Nut 3/8 x 16 (R.H.)	22	697770	Seal, Cover Plate	37	W10168564	Wheel, Blower
9	8066224	Exhaust Pipe	23	8563755	Housing, Outlet	38	8563758	Door, Lint Screen
10	8572105	Clip	24	8573824	Funnel, Burner	39	W10165817	Thermostat 140°F Cycling
11	8066208	Clip, Spring	25	8318215	Drum Complete	40	3387230	Screw
12	338906	Sensor, Radiant	26	W10109200	Screw	41	W10135254	Housing, Blower
13	3390647	Screw	27	W10166807	Seal, Drum	42	8066168	Lint Duct Assembly
14	8573713	Thermal Cut-Off (Includes Item 32)	28	3394986	Spring, Lint Screen	43	3401707	Wire, Jumper
			29	W10131836	Thermostat 155 F Gas			

W10135231 BURNER ASSEMBLY

For Model: MDG17MNAWW0
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10135231 BURNER ASSEMBLY

For Model: MDG17MNAWW0
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	W10135231	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 10–16 x 1/2
9		Orifice, Burner
	234870	Type 1
	234868	Type 2
10	W10141728	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, 8–32 x 1/2
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	W10110395	Pipe, Gas Supply
22	697441	Valve & Union Shut–Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

W10436933 Conversion Kit
(Type 1 and 2)
to Type (4) L.P.G.

BA–156B

OPTIONAL PARTS (NOT INCLUDED)

For Model: MDG17MNAWW0
(White)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

4392067 Kit,
Dryer Repair

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)