




**COMMERCIAL GAS DRYER**

**MODELS:**

MDG18MNAWW0 (White)


# TOP AND CONSOLE PARTS



# TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	W10327105	Switch, Cycle Selection	21	8317340	Cover, Terminal Block
	W10184576	Instructions, Installation	11	W10149462	Switch, Push-To-Start	22	3390814	Screw
	W10167625	Wiring Diagram	12	W10130072	Lamp, Indicator	23	W10136704	Top
2	W10133502	Lights, Indicator Assembly	13	W10133507	Knob	24	W10153155	Harness, Main
3	359625	Screw	14	W10133505	Knob, Control	25	W10155650	Nut, Hex
4	W10135184	Facia-Overlay	15	W10133506	Skirt, Dial	26	W10133501	Cap, Knob
5	W10146429	Nut, 8-32 x 3/8	16	W10205150	Console	27	W10140928	Clip, Knob
6	W10139799	Washer	17	W10131123	Nut, "U"			
7	W10139100	Screw	18	342055	Screw			
8	W10124216	Bracket, Control	19	8317305	Panel, Rear Console			
9	W10157942	Timer, Dryer	20	3390647	Screw			


# CABINET PARTS



# CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3387057	Screw	20	W10440461	Cord, Power	42	W10002600	Screw
2	W10131123	Nut, "U"	21	W10279703	Hinge & Pin Assembly	43		Toe, Panel
3	3391846	Clip, Front Panel	22	8540841	Bolt, Shock Brkt.		697215	White
4	3400077	Screw	23	3391943	Boot, Foot	44	3387242	Seal, Front Panel
5	8564010	Assembly, Switch & Actuator	24	697773	Screw	45	342055	Screw
6	3393909	Screw	25	693152	Bumper	46	3388229	Retainer
7		Cabinet	26	8540842	Nut, Shock Brkt.	47	W10323061	Door, Rear
	8310656	White	27	W10139766	Motor Assembly (60 Hz.)	48	694091	Screw
8	3392100	Foot, Dryer	28	3394341	Pulley, Motor	49	W10322546	Door, Front
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	29	8533974	Screw	50	W10116360	Handle, Door
9	660658	Clamp, Motor	30	W10131172	Belt, Drive	51		Panel, Front
10	W10446781	Spring, Idler	31	3390902	Clip, Door Hinge		W10192882	White
11	3389420	Screw	32	W10135695	Bracket, Motor	52	696144	Strike, Door
12	697750	Plug, Multivent	33	3392186	Washer	53	8539892	Wire, Motor To Belt Switch
13	W10344192	Assembly, Idler	34	686590	Ignitor	54	3392538	Door Catch Assembly
14	3391915	Screw	35	W10141728	Valve, Gas (60 Hz - Complete)	55	3390647	Screw
15	3394331	Cover Plate, Exhaust Plate	36	W10212660	Motor, Sound Pad	56	3390735	Seal, Door
16	W10167613	Wire, Belt Switch	37	279731		57	345670	Lock Top
17	W10191265	Plug, Hinge	38	8564011	Bracket, Switch			Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
18	3393657	Restrainer, Belt	39	W10135231	Burner Assembly (60 Hz)	60	279818	White
19	W10291934	Clip	40	W10155571	Switch, Assembly			
			41	3406109	Switch, Door			


# BULKHEAD PARTS



# BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	18	3387459	Washer	34	697557	Bulkhead, Front
2	693995	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	35	697693	Baffle, Drum
3	8533971	Screw	20	8066168	Assembly, Lint Duct	36	3357011	Screw
4	8066086	Plug, Drum Hole	21	W10314171	Roller, Support	37	W10349492	Wheel, Blower
5	3394346	Assembly, Air Duct	22	697770	Seal, Plate Cover	38	8563758	Door, Lint Screen
6	697813	Seal, Outlet Housing	23	8563755	Housing, Outlet Assembly	39	W10131836	Thermostat
7	697814	Seal, Drum Front	24	8573824	Funnel, Burner	40	3387230	Screw
8	3934666	Nut, Hex	25	8318215	Drum Assembly Complete	41	W10135254	Housing, Blower
9	8066224	Exhaust Pipe	26	W10219342	Screw			
10	8572105	Clip, Exhaust	27	W10166807	Seal, Drum Front			
11	3401707	Jumper, wire	28	3394986	Spring, Lint Screen Door			
12	338906	Sensor, Radiant	29	W10178810	Thermostat			
13	3390647	Screw	30	3392519	Fuse, Thermal (91C)			
14	8573713	Cut-Off, Thermal	31	695240	Screw			
15	W10049370	Screen, Lint	32	3391912	Thermostat, Hi Limit			
16	W10001120	Nut, Hex (Left Hand Thread)	33	8563756	Grille, Outlet			
17	3387809	Bulkhead, Rear						

# BURNER ASSEMBLY





# BURNER ASSEMBLY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10135231	Burner Assembly (60 Hz)	12	694538	Bracket, Coil	26	3389889	Bracket, Support
2	688617	Tube, Burner	13	694540	Coil, 60 Hz. (2 Terminal Main)			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	14	694539	Coil, 60 Hz (Split, 3 Terminal)	W10436933		Conversion Kit (Type 1 and 2) to Type L.P.G.
4	686590	Ignitor	15	694424	Leak Limiter			
5	3393909	Screw	16	694423	Screw, Regulator Adjustment			
6	343641	Screw	17	694422	Spring, Regulator			
7	3389871	Base, Burner						
8	3387057	Screw	20	239822	Plug, Pipe			
9		Orifice, Burner	21	W10110395	Pipe, Gas Supply			
	234870	Type 1	22	697441	Valve, Gas			
	234868	Type 2	23	3393767	Pipe, Tail			
10	W10141728	Valve, Gas (60 Hz - Complete)	24	233076	Nut, Compression			
11	694421	Screw, Coil	25	3387561	Clamp, Pipe			

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4392067	Kit, Dryer Repair

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

## PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White